



Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).


24GHz Loss vs Dew Point




Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).




Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).




Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).




Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).



Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).



Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).



Path Loss Charts. This path loss is ONLY the part due to atmospheric attenuation/absorption. Based on Lieb formulations
Prepared by Brian Justin WA1ZMS. Calculated for Sea Level (standard pressure).

